

Função:	
. Reparar válvula de descarga rápida	
	
Aplicação:	Montagem:
. Aplicável em válvulas descarga rápida Engatcar.	
006001, 006002, 006003, 006004, 006005, 006006, 006007, 006008, 006009	
	